



Último desarrugador de prendas

CLEANING AND STORING

- Turn the ON/OFF switch to the OFF position and unplug from the power source.
- Wait for the steamer to cool completely (at least 30 minutes).
- Unplug power cord and gently wrap around built-in cord wrap.
- Remove the steamer hose.
- Remove the water tank from unit, unscrew valve cap and empty unused contents. Allow to air dry.
- Remove excess water from the reservoir by lifting the unit and pouring into a sink.
- Replace water tank.
- Store the unit.



OTHER IMPORTANT NOTES

During operation, the steamer hose may gurgle. This is a normal result of condensation collecting inside the hose. Simply lift the T-handle upward until the hose is extended to its full height. The gurgle will disappear when the excess moisture inside the hose has had a chance to drain back into the base.

DECALCIFICATION

If the appliance begins to produce steam more slowly than usual, if the steamer stops producing steam and then starts again, or if the low-water indicator lamp illuminates even with water tank full, you may need to decalcify your steamer. Decalcification refers to removing the calcium deposits that form over time on the metal parts of the steamer. For best performance from your Conair® Fabric Steamer, decalcify the unit from time to time. The frequency depends upon the hardness of your tap water and how often you use the steamer.

To decalcify, use a solution of 1/3 white vinegar and 2/3 water in the water tank. Replace the water tank in the unit. Plug the unit into electrical outlet. Turn to the ON position and run until half the amount has steamed (1 liter). Turn the unit to the OFF position, unplug from electrical outlet, and allow to sit for 30 minutes. Remove water tank.

HOW TO STEAM

Grasp the T-handle steam nozzle with the steam jets facing away from you. Begin at the bottom of the fabric to allow the steam to rise inside and outside, removing wrinkles. Slowly move the nozzle from the bottom to the top of the fabric. Remove the nozzle from the garment and smooth the fabric with your free hand. Some fabrics are best steamed on the underside of the material. This will allow the fibers of the fabric to relax, eliminating wrinkles.

NOTE: Test fabric for color fastness in an inconspicuous spot. Drape linens, towels, handkerchiefs and napkins over a rod or place on a towel rack.

Heavier fabrics may require repeated steaming. Repeat as necessary.

CORRECTIVE

With practice, you will gain speed and efficiency. You will soon learn which fabrics require multiple steam applications.

CAUTION

Do not directly touch velvet or silk with the steam head.

ALWAYS STEAM WITH HOSE IN UPRIGHT POSITION, SO ANY CONDENSATION IS FREE TO FLOW BACK INTO THE STEAMER.

If you steam with hose not upright, condensation will collect inside the hose. This will cause gurgling and some water droplets to form near the steam jets on the T-handle.

CAUTION

To avoid this, frequently lift the steam handle upward until the hose is extended to its full height.

TO STEAM DRAPE

Wash and dry drapes as directed according to fabric type. Re-hang drapes and steam drapes when in place.



TROUBLESHOOTING

- PROBLEM** - Steamer fails to heat
CAUSE - Steamer not plugged in
SOLUTION - Plug into electrical outlet
- PROBLEM** - No steam
CAUSE - Water level is low
SOLUTION - Turn ON/OFF switch off and refill water tank
- PROBLEM** - Water drips from nozzle
CAUSE - Condensation in hose
SOLUTION - Hold the hose vertically and allow water to drain back into unit
- PROBLEM** - Nozzle gurgles
CAUSE - Condensation in hose
SOLUTION - Hold the hose vertically and allow water to drain back into unit
- PROBLEM** - Poor steam performance
CAUSE - Sediment in tank
SOLUTION - Decalcify reservoir and water tank

LIMITED ONE-YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials. To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Service Center
Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

Instructions

for Use

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

CONAIR®

de uso

Para su seguridad y para que las instrucciones de uso se comprendan y se sigan de la mejor manera, lea las instrucciones de uso antes de usarlo.

Centro de servicios

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Nota: El agua de la llave puede tener un

servicio de agua
7475 N. Glen Harbor Blvd.

Nota: El agua de la llave

de la llave puede tener un
servicio de agua
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

INSTRUCCIONES

Para su seguridad y para que las instrucciones de uso se comprendan y se sigan de la mejor manera, lea las instrucciones de uso antes de usarlo.

Nota: El agua de la llave

de la llave puede tener un
servicio de agua
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

INSTRUCCIONES

Para su seguridad y para que las instrucciones de uso se comprendan y se sigan de la mejor manera, lea las instrucciones de uso antes de usarlo.

Nota: El agua de la llave

de la llave puede tener un
servicio de agua
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

Solución:

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.

INSTRUCCIONES

Para su seguridad y para que las instrucciones de uso se comprendan y se sigan de la mejor manera, lea las instrucciones de uso antes de usarlo.